



Product Family
PerCap Banded Earplugs
Folding banded protection

Learn more about our products at howardleight.com >
Learn more about hearing conservation at hearforever.org >



Product Numbers & Ordering Information

	Product Numbers	Details
	10 059 52	PerCap SNR 24 H - 27 M - 20 L - 18
	10 059 80	PerCap - replacement pods

Overview

Key Features

- Semi-aural protection, super soft pods rest outside the ear canal opening
- Multiple position wear - over the head, under the chin or behind the neck - provides flexibility in wear
- Compact, folding design easy to store in pocket

PerCap Banded Earplugs

Hazards

- Noise

Regulations

- 29 CFR 1910.95 - OSHA Occupational Noise Exposure (US)
- ANSI S3.19-1974 - Attenuation Test Protocol (US)
- Part II, (R.S.C. 1985, c. L-2) - Canada Labour Code
- Z94.2-1994 - Attenuation Test Protocol (CAN)
- 2003/10/EC - EU Hearing Directive
- 89/686/EEC - EU Directive/PPE
- Category II - EC Category/PPE
- EN-13819-2:2002 - EU Standards
- EN 352-2:2002 - EU Standards
- NOHSC: 1007 (2000) - National Standard for Occupational Noise (AUS/NZ)
- NR 15 - Security and Health of Work, Annexes 1 and 2, n°3.214/1978 - Occupational Noise Regulations (BR)
- ANSI S12.6/1997 - Method B - Attenuation Test Protocol (BR)
- 9001:2008 - ISO

Historical Brand

Bilsom

Specifications

Color	Orange [pod], Black [band]
Pod Shape	Pod
Material	Polyurethane Foam [pod], Plastic [band]
Packaging	Resealable Bag
NRR	21
Canada Class	B(L)
SNR	24
SLC*0	20 dB / Class 3

EU Certifications

- European Directives – 89/686/EEC
- EC Category PPE – Category II
- Standards – EN-13819-2:2002 / EN-13819-1:2002 / EN 352-2:2002

PerCap Banded Earplugs

- EC Certification Number – 961088
- EC Attestation Number – 200422744
- Laboratory – B.G.I.A.

AUS Certifications

- Standardsmark License #1579

Certifications

Instruction Manual - PerCap (global)

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Secured/Hearing_P

INSTRUCTIONS D'UTILISATION 1. Dpliez l'arceau PerCap comme indiqu (Fig. 1-2). 2. Positionnez l'arceau PerCap sous le menton comme indiqu dans la Fig. 3. Placez les bouchons d'oreille l'entre du conduit auditif protger. 3. Le niveau de protection est amlior en tirant l'oreille vers le haut et vers l'arrire lors de l'i

Literature & Documents

Earplug Instruction Poster - EN

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Hearing_Protection

Training & Proper Use

1. Position the band under your chin.
2. Use your hands to press the ear pods well into the ear canal using an inward motion.
3. Protection levels are improved by pulling your ear up and back when fitting as shown.
4. In a noisy environment, lightly press the band inward with your fingertips as shown. You should not notice a significant difference in noise level.
5. Proper Fit – If either or both earplugs do not seem to be fitted properly, remove the earplug and reinsert.
6. Removal – Gently twist earplug while slowly pulling in an outward motion for removal.
7. Acoustical Check – In a noisy environment, with earplugs inserted, cup your hands over your ears and release. Earplugs should block enough noise so that covering your ears with your hands should not result in a significant noise difference.

Additional Information

CARE + MAINTENANCE

- INSPECT – Prior to fitting, examine your earpods for dirt, damage or extreme hardness—discard immediately if compromised.
- CLEAN – Wash pods and bands with mild soap and warm water only. Pat dry with a towel. Do not

PerCap Banded Earplugs

treat with any other substances, as the earpods may degrade and compromise use.

- REPLACE – Replace pods every 2-4 weeks to ensure optimal protection and performance.

Honeywell

[View other region sites](#)

© 2011 Honeywell International Inc.